

## Steps to Rigging a Harpoon 5.2

1. Grab sail bag from the Front Counter. Bag corresponds to hull color (blue or red/orange).
2. Mainsail gets rigged first.
  - a. Feed foot boltrope into boom track
  - b. Attach tack
  - c. Secure outhaul
  - d. Attach head to main halyard with a bowline
  - e. Release mainsheet cleat
  - f. Feed luff boltrope into mast track as the main is raised
3. Rig Jib
  - a. Attach tack of jib to shackle at the base of the forestay
  - b. Attach jib hanks to forestay. Work from the bottom to the top
  - c. Route jibsheet inboard of the shrouds, through the blocks aft of the shrouds, and then into the cam cleats on top of the centerboard trunk
  - d. Tie stopper knots at the ends of the jibsheet
  - e. Raise Jib
4. Insert stern plug
5. Push boat into water and tie off the painter to a dock cleat
6. Lower centerboard
7. Attach rudder and secure it to the boat with a line